

# Anti-Two Block switch

## To measure the maximum allowable hook position



The Krüger Anti-two block switch at the boom tip prevents the hook block from coming into contact with the boom tip.

In operating condition, the Anti-two block switch contact is closed by the counterweight connected to the Anti-two block switch by chains.

When the hook-block reaches maximum allowable position, the contact is opened by the lifting of the counter weight and the circuit is interrupted (fail-safe).

The Anti-two block switch features simple, functional and compact design in its universal field of application.

It can be installed on the main boom as well as any other attachments and is suitable for right or left hand installations.

1. Anti-two block switch
2. Welding plate
3. Chains
4. Counter weight

